Wooden Collet Tray

TG100 - 30 Holes

Allows you to build and store your own collet set


Code	
218260	



ER Spring Collet Chucks

Caterpillar V-Flange and BT







Hold the nut in the vertical position and remove the collet

- Regular to 12,000 RPM, Balanced to 15,000 RPM
- CAT/BT
- Extended length
- Regular
- · Introduce collet into the clamping nut and turn until the eccentric ring of the nut snaps into the groove of the collet

IMPORTANT: Never screw the nut on the collet chuck unless the collet is located in the clamping nut. By unscrewing the clamping nut the collet is withdrawn from the chuck by means of the eccentric ring

ER 16 (1/32 - 3/8) Collet Chucks

Premium

Shank	Gage Length (Inch)	Code	Shank	Gage Length (Inch)	Code
CAT40	5	827336	BT40	2-1/2	827339
CAT50	4	827337	BT40	5	827340

Value

Shank	Gage Length (Inch)	Code	Shank	Gage Length (Inch)	Code
CAT40	2-1/2	827341	BT40	6	827345
CAT40	4	827342	BT50	4	827346
CAT50	6	827343	BT50	6	827347
RT40	Λ	827344			

Value Balanced G6.3

Shank	Gage Length (Inch)	Code	Shank	Gage Length (Inch)	Code
CAT40	2-1/2	827348	CAT40	4	827349

757