


## Long Feeler Gage



- Made of hardened alloy steel
- Meet DIN2275/grade TCI
- Accuracy:  $\pm(3+T/80)$   $\mu\text{m}$ , 'T' is the thickness of leaves in  $\mu\text{m}$




Range (mm)	Thickness of Blades (mm)	No. of Blades	L (mm)	A (mm)	B (mm)	INSIZE No.	Code
0.05-1	0.05, 0.10, 0.15, 0.20, 0.25, 0.30, 0.40, 0.50, 0.60, 0.70,	13	150	135	295	4605-13	283530
0.05-1	0.80, 0.90, 1.00	13	300	285	590	4605-132	283532
0.05-1	0.05, 0.10, 0.15, 0.20, 0.25, 0.30, 0.35, 0.40, 0.45, 0.50,	20	150	135	295	4605-20	283533
0.05-1	0.55, 0.60, 0.65, 0.70, 0.75, 0.80, 0.85, 0.90, 0.95, 1.00	20	200	185	395	4605-201	283534
0.05-1		20	300	285	590	4605-202	283535

## Feeler Gage



- Made of hardened alloy steel
- Meet DIN2275/grade TCI
- Accuracy:  $\pm(3+T/80)$   $\mu\text{m}$ , 'T' is the thickness of leaves in  $\mu\text{m}$



Range (mm)	Thickness of Blades (mm)	No. of Blades	INSIZE No.	Code
0.04-1	0.04, 0.05, 0.06, 0.07, 0.08, 0.09, 0.10, 0.15, 0.20, 0.25, 0.30, 0.35, 0.40, 0.45, 0.50, 0.55, 0.60, 0.65, 0.70, 0.75, 0.80, 0.85, 0.90, 0.95, 1.00	25	4601-25	283523